

# **Acer MP3 Flash Stick**

## **User Manual**

MP3 Music Player+Digital Voice Recorder+USB Flash Drive

## Table of Contents

<b>1. Introduction</b>	
1.1 About Acer MP3 Flash Stick-----	2
1.2 Features -----	2
<b>2. Illustration of function keys and LCD display-----</b>	<b>3</b>
<b>3. Quick start-----</b>	<b>5</b>
<b>4. Function and operation</b>	
4.1 MP3 / WMA playback-----	6
4.2 Recording operation-----	7
4.3 Selection / Fast forward / fast backward-----	8
4.4 Equalizer settings-----	9
4.5 Volume control-----	9
4.6 Key lock-----	9
4.7 Repeat section-----	10
4.8 Menu operation-----	10
4.9 Connect to computer-----	11
<b>5. How to Install / Modify / Repair / Remove driver</b>	
5.1 Windows 98 / 98SE Installation -----	13
5.2 Windows 2000 / ME / XP Installation-----	15
<b>6. Remove Acer MP3 Flash Stick from computer -----</b>	<b>15</b>
<b>7. Linux 2.4.0 + / Mac 8.6 + Installation -----</b>	<b>17</b>
<b>IMPORTANT NOTICES -----</b>	<b>17</b>

---

# 1. Introduction

---

## 1.1 About Acer MP3 Flash Stick

Acer MP3 Flash Stick is the brand new multi-function MP3 player . Compared with the single-function MP3 Player, Acer MP3 Flash Stick owns not only the stylish outlook with an EQ built in LCD, but also the high quality digital voice recorder. We successfully combine the convenience of well-known USB flash drive , popular MP3 player and delicate-design digital voice recorder in one stick . With two AAA batteries, you will take the advantage of 12 hours non-stop playing time. Acer MP3 Flash Stick is suitable for each occasion—for meeting, for data storage and of course, for music enjoyment. It is absolutely your best choice from various consumer products.


## 1.2 Features


- Current available: 64MB / 128MB / 256MB
- Support music format: MP3 / WMA
- Earphone jack: 3.5 mm
- Audio output: 5mW+5mW
- Output frequency range: 20HZ – 20KHZ
- Battery: two of AAA battery.
- Support USB specification revision 1.1
- Transferring rate up to 12Mbit per second at “Full Speed”.
- Support power saving mode to reduce power consumption while no playing Acer MP3 Flash Stick.
- Support Windows 2000, ME, XP, Mac OS 8.6 or above and Linux 2.4.0 or above without device driver.
- Support Windows 98/98SE with device driver.
- LED indicator when Acer MP3 Flash Stick is working.
- Key lock switch.
- Hot Plug & Play - Enable you to install Acer MP3 Flash Stick at anytime.
- Durable solid-state storage – data retention for at least 10 years.
- Erase Cycles: 1,000,000 times
- No external power is required - DC 4.5V ~ 5.5V from USB port.
- Low Power consumption : Write 39.1mA ~ 39.4mA / Read 35.0mA ~ 36.1mA.
- Read/Write Speed of USB interface: Read 800KB / Write 600KB
- Size: approximate 95.2 x 30.0 x 28.5 mm
- Unit weight: approximate 30g (not including battery)
- CE and FCC certificate of approval.

---

## 2. Illustration of function keys and LCD display

---





---

## 3. Quick Start

---

### MP3/WMA Playback

Steps:

1. Press **Switch Controller** to turn on the player.
2. If there are already MP3 or WMA files in the Flash Memory, the LCD will show 「01 0:00」, and the LED will light up. To begin the playback of MP3 or WMA file, press again **Switch Controller**.

### Record Operation

Steps:

1. Press **Switch Controller** to turn on the player.
2. Press **Record Button** to enter record mode and the LCD will show "—HP—". Slide **Switch Controller** to choose record mode, and then press **Record Button** to start recording. LED will blink, and the "REC" icon will show up in the display.
3. Press again **Record Button** to stop record and then enter the record playback mode. The "REC" icon will disappear and the "DVR" icon will show up in the display. LED will light off.
4. To play the previous recorded WAV files, press **Switch Controller** in record playback mode.

### Connecting to PC

Steps:

1. Use USB cable to connect to PC's USB port, the player will be turned on automatically.
2. The USB indication will show up in the LCD. While connecting to PC, LCD will show "USb bSy", and LED will blink.
3. Once the connection is completed, LED will light up, and "---PC--" will appear in the display. You will see a "Removable Disk" in My Computer.

## 4. Function & Operation

### 4.1. MP3/WMA Playback

(1) Press **Switch Controller** to turn on the player which will automatically read the content of the Flash Memory and the LED will light up. If there are already MP3 or WMA files in the Flash Memory, LCD will show as **Figure 4.1.1**.




Figure 4.1.1

(2) Press **Switch Controller** to start playing the first selection. The music format such as MP3 or WMA will be indicated in the display. LED will keep blinking and the selection number as well as the playing time will also be indicated in the display. (**Figure 4.1.2**)




Figure 4.1.2

(3) To pause during playback, press **Switch Controller**, and the pause symbol will appear. Elapsed playing time will be paused, too. (**Figure 4.1.3**). LED will light up instead of flashing.




Figure 4.1.3

(4) Press **Switch Controller** to resume playback.

(5) To stop playing, press **Switch Controller** for 2 seconds, LED will light up instead of blinking, and the playing time will be reset to zero. (**Figure 4.1.5**)




Figure 4.1.5

(6) To set the player to sleep mode, press **Switch Controller** again for 2 seconds in stop mode.

If no operations occurred for 30 seconds in stop mode, the player will enter sleep mode automatically.

To wake up the player, press **Switch Controller**.

(7) If the Flash Memory has not yet been formatted, or problems occur with the files in the Flash Memory, LCD will show "OS Err" as in **Figure 4.1.7**.





Figure 4.1.7

(8) Under this situation, press **Mode Key** and hold until "Eq" appears in the display. **(Figure 4.1.8)**



**Figure 4.1.8**

(9) Slide **Switch controller** until "dEL" appears in the display. Press **Switch controller** again to enter delete mode. Slide **Switch controller** until "dEL aLL" flashes in the display.

(10) Press **Switch controller** again to start formatting the Flash Memory.

To cancel "dEL aLL" action, press **Record Button** or **Mode Key** simultaneously.


(11) During format or delete, LCD will show "EL\_\_\_\_" as in **Figure 4.1.11.**



**Figure 4.1.11**


(12) Once the format of the Flash Memory is completed, the playing time in the display will be reset to zero.

**(Figure 4.1.12)**



**Figure 4.1.12**

(13) To delete a single file of MP3 / WMA in stop mode, press **Mode Key** for 2 seconds to go into the Menu. Slide **Switch Controller** until "dEL" shows up in the display. Press **Switch Controller** again to enter the delete mode. Slide **Switch Controller** until "EL OnE" flashes in the display. **(Figure 4.1.13)**




**Figure 4.1.13**

(14) Press **Switch Controller** again to delete the file selected.

To cancel "dEL OnE" action, press **Record Button** or **Mode Key** simultaneously.

## 4.2. Recording Operation


(1) In stop mode, press **Record Button** to enter record mode, and "--HP--" will appear in the display **(Figure 4.2.1)**. Press **Switch Controller** to select record mode.



**Figure 4.2.1**




- (2) Press **Record Button** to start recording. LED will keep blinking, and the "REC" icon will appear. Elapsed recording time will be shown in the display. **(Figure 4.2.2)**



**Figure 4.2.2**


- (3) To stop record, press **Record Button** again. LED will turn off, and the beginning of the playing time will be indicated in the display. "DVR" icon turns up while "REC" icon disappears. **(Figure 4.2.3)**



**Figure 4.2.3**

To pause the record, press **Switch Controller**. To resume it, press **Switch Controller** again.


- (4) To start play of the previous recorded WAV files in stop mode, press **Switch Controller**. LCD will show the selection number and the playing time. **(Figure 4.2.4)**



**Figure 4.2.4**


To switch between MP3 and record mode in stop mode, press **Mode Key**.

- (5) Press **Switch Controller** to pause the playback, playing time will be paused as well. **(Figure 4.2.5)**
- (6) Press **Switch Controller** to resume playback.



**Figure 4.2.5**

- (7) If the space in the Flash Memory is used up during record, LCD will show "FULL" **(Figure 4.2.7)** and record will stop.




**Figure 4.2.7**

Press any key to go back to record stop mode.

File deletion, selection, fast forward and fast backward in record mode are the same as in MP3 / WMA mode.

### 4.3. Selection / Fast Forward / Fast Backward

- (1) To select during playback, slide **Switch Controller** upward once for the previous file, and downward for the next one. Playback will start from the beginning of the selection. **(Figure 4.3.1)**




**Figure 4.3.1**

- (2) To select in stop mode, slide **Switch Controller** until the desired selection shows up in the display. Press **Switch controller** to start play.
- (3) To locate a particular point in a selection, Slide **Switch Controller** up for fast backward and slide down for fast forward. Playing time in the display will change accordingly. Release **Switch Controller** and the playback will start from the time indicated in the display.

#### 4.4. Equalizer Settings

- (1) Press **Mode Key** for 2 seconds until "Eq" appears in the display. **(Figure 4.4.1)** Press **Switch Controller** to enter the menu of **Equalizer Settings**.




**Figure 4.4.1**

- (2) Slide **Switch Controller** to select the following settings:  
 Normal → POP → JAZZ → CLASSICAL → ROCK → Normal.  
 Press **Switch Controller** again to confirm, then the icon will come out in the display.



#### 4.5. Volume Control

- (1) During playback, slide **Volume Controller** to the left to turn down and right to turn up the volume which will be shown in the display. **(Figure 4.5.1)** -- Sound Level: 0 ~ 63



**Figure 4.5.1**

- (2) To continuously increase or decrease the volume, slide **Volume Controller** to the right / left and hold. To stop volume control, stop sliding **Volume Controller** and the LCD will resume the normal display.

#### 4.6. Key Lock

- (1) Player status: click switch toward to **Switch Controller**, all buttons and switch controller will be locked and no working.
- (2) Removable disk status: click switch toward to **Switch Controller**, writing will be protected.

#### 4.7. Repeat Section

- (1) During playback, press **Record Button** once to enter the repeat read mode. The start point A will be marked. "A-B" icon will appear and "B" starts flashing. **(Figure 4.7.1)**




Figure 4.7.1

- (2) Press **Record Button** again to mark the end point "B" whose icon will stop flashing. A B repeat read will go on. **(Figure 4.7.2)**




Figure 4.7.2

If point "B" is not marked until the end of the selected MP3 file, the playback of the next selection will start and point "A" will disappear.

- (3) During A B repeat read , press **Record Button** again to leave this mode. Normal playback will resume from point "B", and the "A-B" icon will disappear from the display. **(Figure 4.7.3)**




Figure 4.7.3

During A B repeat read , press **Switch Controller** once to pause the repeat read, press **Switch controller** once again to resume it.

#### 4.8. Menu Operation

- (1) Press **Mode Key** to enter Menu operation which contains 3 functions: (1) Equalizer Settings (Eq),  
 (2) Playback Settings (Rep),  
 (3) File Deletion (dEL).

To select, slide **Switch Controller** up and down and the function will change cyclically as follows :

Eq → rEP → dEL → Eq. Press **Switch Controller** again to confirm the selection. **(Figure 4.8.1)**




Figure 4.8.1

- (2) Eq Menu: Under Equalizer Settings, slide **Switch Controller** to select among 5 settings with the following cycle:

Normal → POP → JAZZ → CLASSICAL → ROCK → Normal

Press **Switch Controller** to confirm the setting. **(Figure 4.8.2)**





Figure 4.8.2

(3) rEp Menu: Under playback settings, slide **S1** to select among the following 3 repeat settings:

- (1) Repeat ALL: repeat all the selections
- (2) Repeat 1:repeat a single selection
- (3) NO Repeat: to cancel repeat

Press **Switch Controller** again to confirm the setting.

**(Figure 4.8.3)**




**Figure 4.8.3**

(4) dEL Menu: Under file deletion , slide **Switch Controller** to select among the deletion of a single file or all files with the following cycle: EL ONE→ EL aLL→ EL ONE

Press **Switch Controller** again to confirm the setting.


**(Figure 4.8.4)**



**Figure 4.8.4**


#### **4.9. Connect to Computer**

(1) Use the USB cable to connect to PC's USB port, and the USB indication will show up in the LCD when the player is plugged in. **(Figure 4.9.1)**




**Figure 4.9.1**

(2) During USB operations (including connection with PC, file copy / delete, Flash Memory format), the LED will blink and "USb bSy" will appear in the display. **(Figure 4.9.2)**



**Figure 4.9.2**


(3) Once the connection is completed, LED will light up, and "---PC--" will appear in the display. You will see a "Removable Disk" in My Computer. **(Figure 4.9.3)**



**Figure 4.9.3**

(4) Remove the unit from the USB port of PC to return the player back to stop mode, and the removable disk will disappear from My Computer. Playing time of the 1<sup>st</sup> file will be displayed in the LCD. **(Figure 4.9.4)**

When file copy / delete through PC is finished, make sure the USB operation has come to a complete stop before unplugging the player from PC's USB port. Otherwise it may result in damages to the files in the Flash Memory.



**Figure 4.9.4**


---

## 5. How to install driver


---

### 5.1 Windows 98/98SE Installation :


- (1) Plug Flash Stick into USB port. System will detect one new hardware and search for proper driver to install.



- (2) Choose the first recommend to install.




(3) Choose setting up from CD ROM.



(4) To execute installation by press "Next".



(5) Press "Finish" to complete installation.



## 5.2 Windows ME / Windows 2000 / XP Installation

For these three operating systems, **NO Driver is needed**, because Windows has built-in driver to support USB removable disk. Simply plug Acer MP3 Flash Stick into the USB port and it will be recognized by the system. System will setup Acer MP3 Flash Stick automatically without any further installation of driver.

Once installation is completed, you will see a "Removable Disk" drive in My Computer.

## 6. Remove Acer MP3 Flash Stick from computer

After using Acer MP3 Flash Stick, please choose one of the methods below according to your Operating System to remove Acer MP3 Flash Stick from USB port:

**Windows 98/98SE :** You could unplug Acer MP3 Flash Stick from the USB port directly once the LED stops blinking and its icon would disappear automatically.

**Windows Me/2000/XP :** Click the icon of Acer MP3 Flash Stick at the right down corner, and a "Stop USB Mass Storage Device-Drive(H:)" menu appears (Fig.6.1). Click the menu, and the below window appears telling you "the 'USB Mass Storage Device' device can be safely removed from the system". Click "OK" to close the window (Fig.6.2), then you can safely remove Acer MP3 Flash Stick.






Fig.6.1




Fig.6.2

## 7. Linux 2.4.0 + / Mac 8.6 + Installation

Again, **No Driver is required** for these two operating systems. Simply plug the Acer MP3 Flash Stick into the USB port and the system will automatically find Acer MP3 Flash Stick. After using Acer MP3 Flash Stick, you could unplug Acer MP3 Flash Stick from the USB port directly once the LED stops blinking, then its icon would disappear automatically.

**For Linux user, please refer to Important Notices.**

### **Important Notices :**

- (i) In OS Windows 98/98SE, if you don't set up installation firstly, system will ask you to put driver disk for running installation. Be sure to unplug Acer MP3 Flash Stick before running setup programs. If you install the driver with Acer MP3 Flash Stick plugged, it may cause setup error or failure.
- (ii) If you plug Acer MP3 Flash Stick into the USB port. System can find Acer MP3 Flash Stick, but you are unable to access it. Please **FORMAT** Acer MP3 Flash Stick.
- (iii) Before unplugging Acer MP3 Flash Stick from the USB port in **Windows ME/2000/XP**, make sure you go to the right hand bottom of the screen to stop the USB device. Otherwise, it may result in losing data that you have saved on Acer MP3 Flash Stick. (Please refer to 6.2.)
- (iv) Linux uses a so-called "USB Manager", which does automatically load kernel modules (drivers) for USB devices. It loads only drivers for devices that are present on the USB bus to reduce memory usage. Per default, the USB Manager does not come with the USB Drive pre-configured. However, you can easily configure the USB Manager to automatically recognize the USB Drive yourself. Just add the following to the configuration file,

```
usbmgr.conf (usually in /etc/usbmgr): vendor 0xd7d product 0x100 module scsi_mod,  
usb-storage
```

This line identifies the USB Drive and tells the USB Manager to load the SCSI as well as the USB storage module. The SCSI module is needed in order to talk to both SCSI and USB storage devices, while the usb-storage module is needed to talk to USB storage devices.

Do not forget to either reload the USB Manager's configuration or to restart the USB Manager (for instance, do as root: /etc/init.d/usbmgr reload).